




Schreibtische der H-Serie / Q-Serie

Assembly instruction : desk range H.. / Q..



<p>HS08, HS12, HS16</p> <p>4x 4x</p>	<p>QS08, QS12, QS16</p> <p>4x 4x</p>
<p>HS18</p> <p>4x 4x</p>	<p>QS18</p> <p>4x 4x</p>
<p>HS21</p> <p>4x 4x + 10x (4.5 x 25)</p>	<p>QS21</p> <p>4x 4x + 10x (4.5 x 25)</p>
<p>HS82</p> <p>5x 5x 6x (4.5 x 25)</p>	<p>QS82</p> <p>5x 5x 6x (4.5 x 25)</p>



Schreibtische der H-Serie / Q-Serie

Beipack :
fitting:
8-10 x (A)
(4.5x 55)

8-10 x (A)

41 mm

41 mm

41 mm

Beipack :
fitting:
11 x (A)
(4.5x 55)

11 x (A)

41 mm

41 mm

41 mm

Beipack :
fitting:
12 x (A)
(4.5x 55)

12 x (A)

41 mm

41 mm

41 mm

+
4 x (B)
(4.5 x 25)

Beipack :
fitting:
13 x (A)
(4.5x 55)

13 x (A)

41 mm

41 mm

41 mm