











# AXELENT X-GUARD LITE ASSEMBLY GUIDE MESH

BG Инструкции за монтаж  
CZ Montážní návod  
DE Montageanleitung  
DK Monteringsvejledning  
EE Paigaldusjuhised  
ES Instrucciones de montaje  
FI Kokoamisohje  
FR Les instructions d'assemblage  
GB Assembly instructions  
GR οδηγίες συναρμολόγησης  
HU Összeszerelési utasítások  
IE Treoracha cóimeála

IT Istruzioni di montaggio  
LT Surinkimo instrukcija  
LV Montāžas instrukcijas  
MT Assemblaġġ istruzzjonijiet  
NL Montagehandleiding  
PL Instrukcja montażu  
PT Instruções de montagem  
RO Instrucțiunile de asamblare  
SE Monteringsanvisning  
SI Sestavljanje navodila  
SK Montážny návod



T00-06

x 1



x 2 A



x 1 B



x 1 C



x 2 D

B00-002

x 1



x 2 A



x 2 B



x 2 C



x 1 D

