

## Eazycare Style washable dirt-trapping mat

### Sizes:

60 cm × 85 cm,  
75 cm × 85 cm,  
80 cm × 120 cm,  
85 cm × 150 cm,  
85 cm × 300 cm,

120 cm × 180 cm,  
120 cm × 200 cm,  
120 cm × 240 cm,

150 cm × 200 cm,  
150 cm × 250 cm,  
150 cm × 300 cm

### Special Sizes

up to 240 cm × 550 cm or  
200 cm × 1.000 cm

### Material:

Nylon on 100 %  
nitrile rubber back



### Cleaning instructions

Eazycare Style can be cleaned in several different ways.

- They can be commercially laundered (see Laundering Instructions)
- Vacuumed regularly (daily in high-traffic areas; weekly in lower-traffic applications)
- Cleaned with an extractor, or hosed off as necessary to remove heavy soil.

Hang to dry. Mats should always be dry before they are placed back in service.

### Laundering instructions

1. Flush, 2-3 Min. on a medium water level with a maximum temperature of 49 °C
2. Flush (optional), 2-3 Min. on a medium water level with a maximum temperature of 49 °C
3. Break, 2-3 Min. on a high water level with a maximum temperature of 49 °C
4. Rinse, 2 Min. on a high water level with cold temperature
5. Rinse, 2 Min. on a high water level with cold temperature
6. Extract on low speed, 1-2 Min.
7. Shake out with the drum turning, 1 Min.
8. Extract, on a maximum of 250G, 3-5 Min.
9. Dry (optional), 5-10 Min. with a maximum basket temperature of 82 °C
10. Cool down, 5 Min.

It's recommended that Eazycare Style mats are washed separately from other mats. For heavy soiled mats, increase the temperature up to max. 71 °C. Break should not exceed pH of 9,5; use low pH non-ionic detergents. Do not overdry mats; basket-temperature of the dryer should not exceed 82 °C. If mats are not dried, the final rinse can be increased to 49 °C. This will reduce moisture retention following extraction. Lay mats flat following removal from washer; allow mats to cool before rolling.